



Using Art-Net on an iPad or iPhone

To use an iPhone or iPad with Art-Net a wireless network will be required with a suitable Wi-Fi Access point. This Application Note does not cover how to set up the Wireless Access Point. The iPhone or iPad must be given a static IP address that matches the range being used by the Art-Net devices.

The procedure below is the same for either iPhone or iPad. It is assumed that the IP range is the default one used for Art-Net. If the Art-Net nodes are not on the 2.x.x.x range then simply set the IP address to match the range.

- 1) Turn on 'Wi-Fi' on the iPhone or iPad
- 2) Select the correct network and enter the security key (if required)
- 3) Once connected click on the blue arrow at the right of the 'network'
- 4) Select 'Static'
- 5) Type in the following;
IP : 2.0.0.1 (or similar)
Subnet Mask: 255.0.0.0
The other fields can be left blank
- 6) Click 'Wi-Fi Networks' to save the changes and take you back to the network screen
- 7) Your device will now have a static IP address and can be used on an Art-Net network.

